

mini pops

KORG

T20

SERVICE MANUAL ¼


KEIO ELECTRONIC LAB., CORP.
TOKYO, JAPAN

1 AMP

1 FADE OUT

1 VOLUME

1 POWER SUPPLY



A 2SA 733K
 R 2SC 644R
 S 2SC 6645
 F OUT FF 2SC 945K
 K 2SK 300
 F 1S 1555
 CS, φ 1S 1941

1S 1941-62
 2SA 733K-62
 2SC 644R-62
 2SC 6645-62

2SC 945K-62
 2SK 300-62

1S 1555-62
 1S 1941-62

1S 1941-62
 2SA 733K-62

2SC 644R-62
 2SC 6645-62

2SC 945K-62
 2SK 300-62

1S 1555-62
 1S 1941-62

2/4


SR-120 72ノット用
 3.2Ω24

21-3-13 40
 21-4-25 40
 21-5-17 30

2/4

CHANGE, BREAK FF

KORG MINI POPS-120 OVER ALL CIRCUIT DIAGRAM





CIRCUIT BOARD NUMBER	TERMINAL NUMBER
SLM-36	① ~ ③
SLM-39	④ ~ ⑤

IS1555 or MA150


LED

14





KORG MINI POPS-120 OVER ALL CIRCUIT DIAGRAM



KEIO ELECTRONIC LABORATORY CORP. TOKYO JAPAN

中華書局印行
KOD-A20014